


# INSTRUCTIONS FOR IT™

Congratulations on your purchase of IT™.

IT™ is an amazing new toy.

IT™ moves, IT™ grooves and you are sure to have a lot of fun with IT™.

Please follow the instruction below to set IT™ up.



## BATTERY INSTALLATION

Remove IT™ from all packaging and keep the packaging for future storage.

Your IT™ requires 2 AA Batteries (not included) and the battery compartment is located on the bottom of the unit.

1. Turn IT™ over as shown in Figure 1A.
2. Using a standard philips head (+) screw driver, remove the battery compartment ( As Shown in Figure 1B).
3. Upon opening the battery compartment door place 2 AA batteries into the battery compartment as shown in Figure 1C and then replace the compartment door and screw.

Battery insertion must be done by an adult.

Non-rechargeable batteries are not to be recharged.

Rechargeable batteries are to be removed from the product before being charged (if removable).

Rechargeable batteries are only to be charged under adult supervision (if removable).

Different types of batteries (alkaline, standard or rechargeable) or new and used batteries are not to be mixed.

Only batteries of the same or equivalent types as recommended are to be used.

Batteries are to be inserted with the correct polarity.

Exhausted batteries are to be removed from the product.

The supply terminals are not to be short-circuited.

Dispose of batteries safely and correctly.

Do not attempt to burn batteries.

Remove batteries if the product will not be used for a long period of time.

Do not leave battery powered devices switched "On" after the batteries are exhausted or weak, battery leakage may occur.

Figure 1A




Figure 1B




Figure 1C

